



MM[®] GID Series Expansion Joint

Galvanized Impact Damping System

DESCRIPTION

The GID Series expansion joint is designed for wide expansion joint openings with the ability to facilitate heavy loading. Recessed convex curved slide plates allow the system to accommodate vertical deck deflection. Rubber high-density impact damping base pads absorb traffic impact loads and accommodate minor deck deflection. The flexible fabric reinforced rubber gutter in conjunction with rubber base pads enhances the system's waterproofing capability.

BASIC USE

GID is a traffic bearing expansion joint for parking structures (convention centers, concourse areas, etc.) and other open-air structures requiring a heavy-duty load bearing design. Contact MM Systems for flush aluminum AID Series designs.

FEATURES


- For wide joints with recessed concrete blockouts.
- Accommodates vertical deck deflection.
- AASHTO HS-20 load carrying capability.
- Convex slide plate also available in stainless steel and aluminum.
- Complies with ADA guidelines.
- Impact damping rubber base pads.
- Integral fabric reinforced continuous rubber gutter.

SPECIAL FEATURES

- Available with optional flexible train tube assemblies.
- Fire Barriers - MM expansion joint systems are available with 2 - 4 hour fire protection ratings.

STORAGE

- Store in a dry location prior to use. Read and follow labels and Material Safety Data Sheet before use.



PACKAGING

Galvanized steel slide plates covers supplied in 10-foot lengths and shipped on wooden pallets.

Hardware and other accessories packaged in cardboard cartons.

Fabric Reinforced Rubber Gutter is supplied in longest possible lengths shipped on pallets or spools.

PRECAUTIONS

Adhesives - Use splash goggles and chemical resistant gloves to avoid prolonged or repeated skin contact. Use with adequate ventilation. In case of eye contact, immediately flush (low pressure) with lukewarm water. In case of skin contact, immediately wash skin with soap and water. Read and follow labels and Material Safety Data Sheet before use.

LIMITATIONS


- Concrete blockouts must be properly formed, finished and have sound substrate.
- Joints located in turning lanes or exposed to forklift traffic must be engineered for greater impact loads – contact MM Systems.

MM[®] GID Series Expansion Joint

SELECTION GUIDE

Model Number	Total Movement		Joint Opening "A"						Slide Plate "B"		Blockout "C"	
			Min.		Nominal		Max.					
GID-200	3.0	76	0.0	0	2.0	51	3.0	76	7.0	178	4.125	105
GID-300	4.5	114	0.0	0	3.0	76	4.5	114	8.5	216	5.125	130
GID-400	6.0	152	0.0	0	4.0	102	6.0	152	10.0	254	6.125	156
GID-500	7.5	191	0.0	0	5.0	127	7.5	191	11.5	292	7.125	181
GID-600	9.0	229	0.0	0	6.0	152	9.0	229	13.0	330	8.125	206
GID-700	10.5	267	0.0	0	7.0	178	10.5	267	14.5	368	9.125	232
GID-800	12.0	305	0.0	0	8.0	203	12.0	305	16.0	406	10.125	257
GID-900	13.5	343	0.0	0	9.0	229	13.5	343	17.5	445	11.125	283
GID-1000	15.0	381	0.0	0	10.0	254	15.0	381	19.0	483	12.125	308

Dimensions are shown in **inches** (bold) and millimeters. See web site for GID-C Movement Table. Contact MM Systems for larger sizes and project specific designs.



LIMITED WARRANTY

MM Systems warrants the MM Galvanized Impact Damping System to be free of defects in material and conform to technical data listed. We make no warranty as to color or appearance. Since methods of application can affect performance and on site conditions are beyond our control, MM Systems makes no other warranty, expressed or implied, including warranties of MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. MM Systems sole obligation shall be, at its option, to replace, or to refund the purchase price of the quantity of system proved to be defective. In no event shall MM Systems be liable for any special, incidental, consequential, loss of profits or punitive damages. Other warranties may be available when installed by a MM Certified Contractor.

INSTALLATION

- 1) Remove and repair all unsound concrete in and around the blockout. All spalls must be repaired with compatible patching material.
- 2) Prepare substrate by sandblasting. The blockout must be clean and dry prior to installation and bonding of rubber base pad.
- 3) Install fabric reinforced rubber gutter with rubberized waterproofing tape.
- 4) Apply bedding compound over entire blockout bottom with a notched trowel.
- 5) Install rubber base pad over rubber gutter into bedding compound.
- 6) Install GID slide plate with epoxy insert anchors supplied.
- 7) Mask-off top of deck parallel with edge of blockout on each side of the expansion joint.
- 8) Fill edge voids with sealant supplied by others.
- 9) Torque hardware per the GID Installation Guideline.
- 10) Refer to the GID Installation Guideline for detailed step-by-step instructions.

MM Systems reserves the right to amend or withdraw information contained herein, without notice, and will not be liable for any inaccuracy or ambiguity of said information.

Current Issue 3-07-09



Spec Data